
Ambient Weather PM2.5 Wireless Indoor / Outdoor Particulate Monitor User Manual



Table of Contents

1. Introduction.....	1
1.1 Parts List	2
1.2 Recommend Tools.....	2
1.3 Warnings	2
1.4 Sensor Overview	3
2. Sensor Setup.....	3
2.1 Inserting the Batteries	3
2.2 Recharging the Batteries	4
3. Sensor Installation.....	4
3.1 Sensor Mounting	4
3.1.1 Mounting Guidelines.....	4
3.1.2 Mounting Screws	4
3.2 Best Practices for Wireless Communication	5
4. Specifications.....	6
4.1 Measurement Specifications	6
4.2 Wireless Specifications	6
4.3 Power Specifications.....	6
5. Liability Disclaimer	6
6. FCC Statement	7
7. Warranty Information.....	7

1. Introduction

Thank you for your purchase of the Ambient Weather PM2.5 WiFi Indoor / Outdoor Particulate Monitor. The following user guide provides step by step instructions for installation, operation and troubleshooting. To download the latest manual, compatible devices, and additional troubleshooting tips, please visit:

<https://ambientweather.net/product/pm25>

PM2.5 refers to particles that are 2.5 microns or smaller in diameter. This sensor uses laser scattering to radiate suspending particles in the air, then collects scattering light to obtain the curve of scattering light change with time. The microprocessor calculates equivalent particle diameter and the number of particles with different diameter per unit volume.

The following table describes the Air Quality Index (AQI) vs. PM2.5 breakpoints.

AQI Category	Breakpoints ($\mu\text{g}/\text{m}^3$)
Good	0.0 – 12.0
Moderate	12.1 – 35.4
Unhealthy for Sensitive Groups	35.5 – 55.4
Unhealthy	55.5 – 150.4
Very Unhealthy	150.5 – 250.4
Hazardous	250.5 – 350.4
Extremely Hazardous	350.5 – 500

Figure 1


1.1 Parts List

QTY	Item
1	PM2.5 Sensor
1	USB Charging Cable
2	Ni-MH Rechargeable Batteries
4	Mounting Screws
1	User manual

1.2 Recommend Tools

Precision screwdriver for mounting screws.

1.3 Warnings

 **Warning: Only use Ni-MH Rechargeable Batteries.** Do not use any other battery chemistry. Using batteries other than the prescribed Ni-MH may result in battery explosion when charging.

1.4 Sensor Overview




Figure 2

No	Description	No	Description
1	Solar Collector	4	Blue LED Indicator (charging status)
2	Battery Compartment Cover	5	USB Charging Port
3	Red LED Indicator (RF transmission)	6	Battery Compartment

2. Sensor Setup

2.1 Inserting the Batteries

Remove the battery cover on the bottom of the sensor, and insert the 2 x AA Ni-MH Rechargeable Batteries.

After inserting the batteries, the sensor LED indicator will light for four seconds, and then flash once per 10 minutes thereafter. Each time it flashes, the sensor is transmitting data.

Close the battery door.

2.2 Recharging the Batteries

When there is no solar energy, a fully charged set of batteries can last for about 20 days (approximately 500 hours). A low battery indicator will appear on the display console.

To recharge the batteries:

Remove the battery cover on the bottom of the sensor.

Connect the USB cable to a standard USB power adapter and charge battery until blue LED turns off, indicating batteries are fully charged.

Once charged, disconnect the USB charging cable.

Close the battery door.

3. Sensor Installation

3.1 Sensor Mounting

3.1.1 Mounting Guidelines

Mount in a well-drained area. An example of a good mounting location is on the top of a post. If the sensor is mounted in a pool of water, it will read incorrectly and may degrade the life of the sensor. An example of a poor mounting location is a table or ground where water can collect.

Mounting orientation is not important. It can be mounted vertically or horizontally, as long as the vents are not blocked.

3.1.2 Mounting Screws

Open the battery compartment.

Use four screws to fix the base of the sensor on a flat surface.

Close the battery compartment.




Figure 3

3.2 Best Practices for Wireless Communication

Wireless communication is susceptible to interference, distance, walls and metal barriers. We recommend the following best practices for trouble free wireless communication.

1. **Electro-Magnetic Interference (EMI).** Keep the console several feet away from computer monitors and TVs.
2. **Radio Frequency Interference (RFI).** If you have other 433 MHz devices and communication is intermittent, try turning off these other devices for troubleshooting purposes. You may need to relocate the transmitters or receivers to avoid intermittent communication.
3. **Line of Sight Rating.** This device is rated at 300feet line of sight (no interference, barriers or walls) but typically you will get 100feet maximum under most real-world installations, which include passing through barriers or walls.

4. **Metal Barriers.** Radio frequency will not pass through metal barriers such as aluminum siding. If you have metal siding, align the remote and console through a window to get a clear line of sight. The following is a table of reception loss vs. the transmission medium. Each “wall” or obstruction decreases the transmission range by the factor shown below.

Medium	RF Signal Strength Reduction
Glass (untreated)	5-15%
Plastics	10-15%
Wood	10-40%
Brick	10-40%
Concrete	40-80%
Metal	90-100%

4. Specifications

4.1 Measurement Specifications

Measurement	Range	Accuracy	Resolution
PM 2.5	0~999ug/m ³	>100ug/m ³ , ±15% <100ug/m ³ , ±15ug/m ³ (at 25°C ±5°C)	1ug/m ³

4.2 Wireless Specifications

Transmission distance in open field: 300 feet line of sight, 100 feet under most conditions.

Frequency: 915 MHz

Sensor reporting interval: 10 minutes

4.3 Power Specifications

PM2.5 sensor: 2 x AA 1.2V LSD type NI-MH batteries (included)

Solar panel for backup power

5. Liability Disclaimer

Please help in the preservation of the environment and return used batteries to an authorized depot.

The electrical and electronic wastes contain hazardous substances. Disposal of electronic waste in wild country and/or in unauthorized grounds strongly damages the environment.

Reading the “User manual” is highly recommended. The manufacturer and supplier cannot accept any responsibility for any incorrect readings and any consequences that occur should an inaccurate reading take place.

This product is designed for use in the home only as indication of weather conditions. This product is not to be used for medical purposes or for public safety information.

The specifications of this product may change without prior notice.

This product is not a toy. Keep out of the reach of children.

No part of this manual may be reproduced without written authorization of the manufacturer.

Ambient, LLC WILL NOT ASSUME LIABILITY FOR INCIDENTAL, CONSEQUENTIAL, PUNITIVE, OR OTHER SIMILAR DAMAGES ASSOCIATED WITH THE OPERATION OR MALFUNCTION OF THIS PRODUCT.

6. FCC Statement

Statement according to FCC part 15.19:

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

Statement according to FCC part 15.21:

Modifications not expressly approved by this company could void the user's authority to operate the equipment.

Statement according to FCC part 15.105:

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

7. Warranty Information

Ambient, LLC provides a 1-year limited warranty on this product against manufacturing defects in materials and workmanship.

This limited warranty begins on the original date of purchase, is valid only on products purchased and only to the original purchaser of this product. To receive warranty service, the purchaser must contact Ambient, LLC for problem determination and service procedures.

Warranty service can only be performed by a Ambient, LLC. The original dated bill of sale must be presented upon request as proof of purchase to Ambient, LLC.

Your Ambient, LLC warranty covers all defects in material and workmanship with the following specified exceptions: (1) damage caused by accident, unreasonable use or neglect (lack of reasonable and necessary maintenance); (3) damage resulting from failure to follow instructions contained in your owner's manual; (4) damage resulting from the performance of repairs or alterations by someone other than an authorized Ambient, LLC authorized service center; (5) units used for other than personal use

(6) applications and uses that this product was not intended (7) the products inability to receive a signal due to any source of interference or metal obstructions and (8) extreme acts of nature, such as lightning strikes or floods.

This warranty covers only actual defects within the product itself, and does not cover the cost of installation or removal from a fixed installation, normal set-up or adjustments, claims based on misrepresentation by the seller or performance variations resulting from installation-related circumstances.

